



## Akumulator DMW-BCK7

Cena	<b>39,90 zł</b>
Dostępność	<b>Dostępny</b>
Czas wysyłki	<b>1-2 dni robocze</b>
Numer katalogowy	<b>bz213250</b>
Producent	<b>CS</b>

### Opis produktu

#### Akumulator typu Panasonic DMW-BCK7E

Zamiennik akumulatorów Panasonic:

- **DMW-BCK7, DMW-BCK7E, DMW-BCK7PP**
- **NCA-YN101F, NCA-YN101H, NCA-YN101G**
- **VW-BCK7**

### Specyfikacja

- Li-Ion, 650 mAh, 2,4Wh, 3,7V
- wymiary: 41,1 x 36,5 x 5,6 mm
- waga: 12 g
- zastępuje akumulatory o napięciach 3,6V i 3,7V

Rzeczywista pojemność i najwyższa jakość - wysokiej klasy zamiennik.

### Bateria DMW-BCK7 pasuje m.in. do aparatów cyfrowych Panasonic:

- Lumix DMC-FH2, DMC-FH2A, DMC-FH2GF, DMC-FH2GH, DMC-FH2GK, DMC-FH2K, DMC-FH2N, DMC-FH2P, DMC-FH2S
- Lumix DMC-FH4, DMC-FH4GK, DMC-FH4K, DMC-FH4P, DMC-FH4S
- Lumix DMC-FH5, DMC-FH5GA, DMC-FH5GK, DMC-FH5K, DMC-FH5P, DMC-FH5S, DMC-FH5V
- Lumix DMC-FH6, DMC-FH6GF, DMC-FH6GK, DMC-FH6K, DMC-FH6P, DMC-FH6S, DMC-FH6Y
- Lumix DMC-FH7, DMC-FH7GH, DMC-FH7GK, DMC-FH7GN, DMC-FH7GT, DMC-FH7K, DMC-FH7P
- Lumix DMC-FH8, DMC-FH8GA, DMC-FH8GC, DMC-FH8GF, DMC-FH8K, DMC-FH8R, DMC-FH8S
- Lumix DMC-FH24, DMC-FH24GK, DMC-FH24K, DMC-FH24P
- Lumix DMC-FH25, DMC-FH25GH, DMC-FH25K, DMC-FH25PU
- Lumix DMC-FH27, DMC-FH27GF, DMC-FH27K, DMC-FH27P, DMC-FH27R, DMC-FH27S
- Lumix DMC-FP5, DMC-FP5A, DMC-FP5G, DMC-FP5K, DMC-FP5P, DMC-FP5S
- Lumix DMC-FP7, DMC-FP7A, DMC-FP7K, DMC-FP7N, DMC-FP7P, DMC-FP7R, DMC-FP7S
- Lumix DMC-FS14, DMC-FS14GK, DMC-FS14K, DMC-FS14R
- Lumix DMC-FS16, DMC-FS16A, DMC-FS16EG, DMC-FS16P, DMC-FS16R, DMC-FS16S
- Lumix DMC-FS18, DMC-FS18EB, DMC-FS18EE, DMC-FS18EF, DMC-FS18EG, DMC-FS18P, DMC-FS18S, DMC-FS18V
- Lumix DMC-FS22, DMC-FS22EE, DMC-FS22EF, DMC-FS22EG, DMC-FS22K, DMC-FS22N, DMC-FS22P, DMC-FS22S
- Lumix DMC-FS28, DMC-FS28GK, DMC-FS28K, DMC-FS28P, DMC-FS28S
- Lumix DMC-FS35, DMC-FS35A, DMC-FS35EB, DMC-FS35EE, DMC-FS35EG, DMC-FS35EP, DMC-FS35GK, DMC-FS35K
- Lumix DMC-FS37, DMC-FS37EB, DMC-FS37EE, DMC-FS37EG, DMC-FS37EP, DMC-FS37GK, DMC-FS37K, DMC-FS37R, DMC-FS37S
- Lumix DMC-FS40, DMC-FS40A, DMC-FS40EG, DMC-FS40EP, DMC-FS40GK, DMC-FS40K, DMC-FS40P, DMC-FS40S, DMC-FS40Y
- Lumix DMC-FS41, DMC-FS41EB, DMC-FS41EE, DMC-FS41EG, DMC-FS41EP, DMC-FS41GK
- Lumix DMC-FS45, DMC-FS45EB, DMC-FS45EE, DMC-FS45EP, DMC-FS45GK, DMC-FS45K, DMC-FS45S, DMC-FS45V
- Lumix DMC-FT20, DMC-FT20A, DMC-FT20D, DMC-FT20EF, DMC-FT20EG, DMC-FT20GF, DMC-FT20GK, DMC-FT20K, DMC-FT20R
- Lumix DMC-FT25, DMC-FT25EB, DMC-FT25EB-A, DMC-FT25EB-K, DMC-FT25EG-A, DMC-FT25EG-K
- Lumix DMC-FT30, DMC-FT30EP



- 
- Lumix DMC-FX77, DMC-FX77A, DMC-FX77K, DMC-FX77N, DMC-FX77P, DMC-FX77S, DMC-FX77W
  - Lumix DMC-FX78, DMC-FX78A, DMC-FX78K, DMC-FX78N, DMC-FX78P, DMC-FX78S, DMC-FX78W
  - Lumix DMC-FX80, DMC-FX80K, DMC-FX80N, DMC-FX80P, DMC-FX80V, DMC-FX80W, DMC-FX80EB
  - Lumix DMC-FX90, DMC-FX90EB, DMC-FX90EG, DMC-FX90K, DMC-FX90P
  - Lumix DMC-S1, DMC-S1A, DMC-S1K, DMC-S1N, DMC-S1P, DMC-S1PA, DMC-S1S, DMC-S1W
  - Lumix DMC-S2, DMC-S2EB, DMC-S2EE, DMC-S2K, DMC-S2P, DMC-S2PU, DMC-S2R, DMC-S2V, DMC-S2W
  - Lumix DMC-S3, DMC-S3A, DMC-S3K, DMC-S3R, DMC-S3V, DMC-S3W
  - Lumix DMC-S5, DMC-S5EB, DMC-S5EE, DMC-S5EF, DMC-S5EG, DMC-S5K, DMC-S5R, DMC-S5S
  - Lumix DMC-SZ02, DMC-SZ02GK, DMC-SZ02P
  - Lumix DMC-SZ1, DMC-SZ1A, DMC-SZ1EB, DMC-SZ1EE, DMC-SZ1EF, DMC-SZ1K, DMC-SZ1P, DMC-SZ1R, DMC-SZ1S
  - Lumix DMC-SZ5, DMC-SZ5EB, DMC-SZ5EG, DMC-SZ5GK, DMC-SZ5K, DMC-SZ5W
  - Lumix DMC-SZ7, DMC-SZ7EB, DMC-SZ7EE, DMC-SZ7EF, DMC-SZ7EG, DMC-SZ7GK, DMC-SZ7K, DMC-SZ7P, DMC-SZ7W
  - Lumix DMC-TS20, DMC-TS20A, DMC-TS20D, DMC-TS20GH, DMC-TS20GK, DMC-TS20K, DMC-TS20P, DMC-TS20R
  - Lumix DMC-TS25, DMC-TS25A, DMC-TS25K, DMC-TS25R, DMC-TS25W

---

## **Akumulator DMW-BCK7 do aparatu cyfrowego Panasonic**

