

Dane aktualne na dzień: 16-05-2025 10:19

Link do produktu: <https://sklepvideo.pl/kabel-panasonic-k1ha08cd0008-p-6111.html>



Kabel A/V K1HA08CD0008

Cena	99,90 zł
Dostępność	Dostępny
Czas wysyłki	1-2 dni robocze
Numer katalogowy	ai101078
Kod producenta	F659624
Producent	Panasonic

Opis produktu

Kabel połączeniowy sygnału audio/video PANASONIC K1HA08CD0008

Oryginalny kabel AV firmy Panasonic, umożliwia podłączenie aparatu do telewizora, nagrywarki itp.

- wyjścia: 1 x video Cinch (RCA), 1 x audio Cinch (RCA) mono
- długość: 1,5 m



Do aparatów wyposażonych w złącze multi AV/USB 8 pin

Zastępuje również kabel o symbolu **K1HY08YY0038**, K1HA08CD0014, K1HA08CD0020, DMW-AVC1, DMW-AVC1E

Do aparatów cyfrowych **Panasonic Lumix**.

Pasuje m.in. do modeli Panasonic:

- DMC-3D1
- DMC-F2, DMC-F3, DMC-F4, DMC-F5
- DMC-FH1, DMC-FH2, DMC-FH3, DMC-FH4, DMC-FH5, DMC-FH6, DMC-FH7, DMC-FH8, DMC-FH10, DMC-FH20, DMC-FH22, DMC-FH24, DMC-FH25, DMC-FH27
- DMC-FP1, DMC-FP2, DMC-FP3, DMC-FP5, DMC-FP7, DMC-FP8
- DMC-FS1, DMC-FS2, DMC-FS3, DMC-FS4, DMC-FS5, DMC-FS6, DMC-FS7, DMC-FS8, DMC-FS9, DMC-FS10, DMC-FS11,

-
- DMC-FS12, DMC-FS14, DMC-FS15, DMC-FS16, DMC-FS18, DMC-FS20, DMC-FS22, DMC-FS25, DMC-FS28, DMC-FS30, DMC-FS33, DMC-FS35, DMC-FS37, DMC-FS40, DMC-FS41, DMC-FS42, DMC-FS45, DMC-FS50, DMC-FS62, DMC-FS70
- DMC-FT3, DMC-FT4, DMC-FT5, DMC-FT10, DMC-FT20, DMC-FT25
 - DMC-FX01, DMC-FX3, DMC-FX07
 - DMC-FX7, DMC-FX8, DMC-FX9
 - DMC-FX10, DMC-FX12, DMC-FX15
 - DMC-FX30, DMC-FX33, DMC-FX35
 - DMC-FX36, DMC-FX37, DMC-FX38
 - DMC-FX40, DMC-FX48, DMC-FX50, DMC-FX55
 - DMC-FX60, DMC-FX66, DMC-FX68
 - DMC-FX70, DMC-FX75, DMC-FX77, DMC-FX78, DMC-FX90
 - DMC-FX100, DMC-FX101
 - DMC-FX150, DMC-FX180
 - DMC-FX500, DMC-FX520, DMC-FX580, DMC-FX700
 - DMC-FZ1, DMC-FZ2, DMC-FZ3
 - DMC-FZ4, DMC-FZ5, DMC-FZ7, DMC-FZ8
 - DMC-FZ10, DMC-FZ15, DMC-FZ18
 - DMC-FZ20, DMC-FZ25, DMC-FZ28
 - DMC-FZ30, DMC-FZ47, DMC-FZ48, DMC-FZ50
 - DMC-FZ60, DMC-FZ62, DMC-FZ150, DMC-FZ200
 - DMC-G1, DMC-G2, DMC-G10
 - DMC-GF1
 - DMC-GX1, DMC-GX7
 - DMC-L10
 - DMC-LS1, DMC-LS2, DMC-LS3
 - DMC-LS6
 - DMC-LS60, DMC-LS65, DMC-LS70
 - DMC-LS75, DMC-LS80, DMC-LS85
 - DMC-LX1, DMC-LX2, DMC-LX3
 - DMC-LZ1, DMC-LZ2, DMC-LZ3
 - DMC-LZ4, DMC-LZ5, DMC-LZ6,
 - DMC-LZ7, DMC-LZ8, DMC-LZ10
 - DMC-SZ3, - DMC-SZ5, - DMC-SZ7, DMC-SZ9
 - DMC-SZ10, DMC-SZ20, DMC-SZ25, DMC-SZ30
 - DMC-TZ1, DMC-TZ2, DMC-TZ3
 - DMC-TZ4, DMC-TZ5, DMC-TZ8
 - DMC-TZ11, DMC-TZ15, DMC-TZ18, DMC-TZ19
 - DMC-TZ20, DMC-TZ22
 - DMC-TZ24, DMC-TZ25, DMC-TZ27
 - DMC-TZ30, DMC-TZ31, DMC-TZ35
 - DMC-TZ36, DMC-TZ37
 - DMC-TZ40, RMC-TZ41
 - DMC-TZ50, DMC-TZ57
 - DMC-TZ60, DMC-TZ70
 - DMC-SD4090, DMC-SD5000
 - DMC-ZR1
 - SVSD300, SVSD310, SVSD710

Do połączenia aparatu z telewizorem lub innym sprzętem wyposażonym w analogowe wejście wizji i fonii.