

Link do produktu: <https://sklepWideo.pl/kabel-usb-panasonic-k1ha08cd0007-p-5967.html>

## Kabel USB K1HA08CD0007



Cena	<b>34,90 zł</b>
Dostępność	<b>Trwale niedostępny</b>
Numer katalogowy	<b>ai102078</b>
Producent	<b>Panasonic</b>

### Opis produktu

**Uwaga - kabel K1HA08CD0007 nie jest już produkowany. Zastępuje go dostępny w naszej ofercie kabel Panasonic**



**K1HY08YY0040.**

symbolach:

Oryginalny kabel Panasonic, zastępuje kable o następujących

- K1HA08CD0004
- K1HA08CD0007
- K1HA08CD0013
- K1HA08CD0019

Kabel służy do transmisji danych między aparatem i komputerem a także, w niektórych modelach do ładowania akumulatora. Kabel pasuje do aparatów wyposażonych w złącze mini USB 8-pin, którego wygląd przedstawiono na zdjęciu obok.

Poniżej lista kompatybilnych modeli aparatów:

- DMC-3D1
- DMC-F2, DMC-F3, DMC-F4, DMC-F5
- DMC-FH1, DMC-FH2, DMC-FH3, DMC-FH4, DMC-FH5, DMC-FH6, DMC-FH7, DMC-FH8, DMC-FH10, DMC-FH20, DMC-FH22, DMC-FH24, DMC-FH25, DMC-FH27
- DMC-FP1, DMC-FP2, DMC-FP3, DMC-FP5, DMC-FP7, DMC-FP8
- DMC-FS1, DMC-FS2, DMC-FS3, DMC-FS4, DMC-FS5, DMC-FS6, DMC-FS7, DMC-FS8, DMC-FS9, DMC-FS10, DMC-FS11, DMC-FS12, DMC-FS14, DMC-FS15, DMC-FS16, DMC-FS18, DMC-FS20, DMC-FS22, DMC-FS25, DMC-FS28, DMC-FS30, DMC-FS33, DMC-FS35, DMC-FS37, DMC-FS40, DMC-FS41, DMC-FS42, DMC-FS45, DMC-FS50, DMC-FS62, DMC-FS70
- DMC-FT3, DMC-FT4, DMC-FT5, DMC-FT10, DMC-FT20, DMC-FT25
- DMC-FX01, DMC-FX3, DMC-FX07
- DMC-FX7, DMC-FX8, DMC-FX9



- DMC-FX10, DMC-FX12, DMC-FX15
- DMC-FX30, DMC-FX33, DMC-FX35
- DMC-FX36, DMC-FX37, DMC-FX38
- DMC-FX40, DMC-FX48, DMC-FX50, DMC-FX55
- DMC-FX60, DMC-FX66, DMC-FX68
- DMC-FX70, DMC-FX75, DMC-FX77, DMC-FX78, DMC-FX90
- DMC-FX100, DMC-FX101
- DMC-FX150, DMC-FX180
- DMC-FX500, DMC-FX520, DMC-FX580, DMC-FX700
- DMC-FZ1, DMC-FZ2, DMC-FZ3
- DMC-FZ4, DMC-FZ5, DMC-FZ7, DMC-FZ8
- DMC-FZ10, DMC-FZ15, DMC-FZ18
- DMC-FZ20, DMC-FZ25, DMC-FZ28
- DMC-FZ30, DMC-FZ47, DMC-FZ48, DMC-FZ50
- DMC-FZ60, DMC-FZ62, DMC-FZ150, DMC-FZ200
- DMC-G1, DMC-G2, DMC-G10
- DMC-GF1
- DMC-L10
- DMC-LS1, DMC-LS2, DMC-LS3
- DMC-LS6
- DMC-LS60, DMC-LS65, DMC-LS70
- DMC-LS75, DMC-LS80, DMC-LS85
- DMC-LX1, DMC-LX2, DMC-LX3
- DMC-LZ1, DMC-LZ2, DMC-LZ3
- DMC-LZ4, DMC-LZ5, DMC-LZ6,
- DMC-LZ7, DMC-LZ8, DMC-LZ10
- DMC-TZ1, DMC-TZ2, DMC-TZ3, DMC-TZ4, DMC-TZ5
- DMC-TZ11, DMC-TZ15, DMC-TZ18, DMC-TZ19
- DMC-TZ20, DMC-TZ22, - DMC-TZ24, DMC-TZ25, DMC-TZ27
- DMC-TZ30, DMC-TZ31, DMC-TZ35, DMC-TZ36, DMC-TZ37
- DMC-TZ40, RMC-TZ41
- DMC-TZ50, DMC-TZ55, DMC-TZ56, DMC-TZ57, DMC-TZ58
- DMC-TZ60, DMC-TZ61
- DMC-TZ70, DMC-TZ71
- DMC-SD4090, DMC-SD5000
- DMC-ZR1
- SVSD300, SVSD310, SVSD710

i wielu innych wyposażonych w złącze mini USB typu 8-pin.

Zastępuje również kable innych producentów:

- Fuji P10NA00990A, Type IV, FZ06584-100, FZ06584-101, FZ06585-101
- Panasonic K1HA08CD0007, K1HA08CD0013, K1HA08CD0019
- Konica Minolta USB-2, Konica Minolta USB-3
- Nikon Part # YM080315, UCE6, UC-E6
- Olympus 202059, CB-USB7, P645-083-1355
- Pentax I-USB7, I-USB17, I-USB33
- Sony 183306211, 183431111, 319698101, 35618-FF-147
- Sanyo USBMB8P-ROUND06

