



## Zasilacz VSK0325 / AC-3VN

Cena	<b>99,90 zł</b>
Dostępność	<b>Dostępny do 3 dni</b>
Czas wysyłki	<b>3-4 dni robocze</b>
Numer katalogowy	<b>zs213240</b>
Producent	<b>B&amp;W</b>

### Opis produktu

#### Zasilacz/ładowarka do Fuji / Panasonic

- 3V / 2A
- wymiary: 81 x 47 x29 cm
- waga: 142 g

Wymiary wtyczki: zewnątrz 2,35 mm, wewnątrz 0,7 mm.

W zestawie kabel zasilający z wtyczką europejską.

#### Zastępuje zasilacze:

- 1543855115
- 600003504
- AC3AG, AC-3AG, AC3V, AC-3V, AC3VHSUS, AC-3VHS-US, AC-3VHS-US, AC3VN, AC-3VN, AC-3VN, AC3VS, AC-3VS, AC-3VS
- DMW-AC1
- KWS0325
- PAN0325B
- VSK0325

#### Stosowany w aparatach:

##### Fuji:

- DS-10
- FinePix 1300
- FinePix 1500
- FinePix 2300
- FinePix 2400
- FinePix 2600
- FinePix 2600 zoom
- FinePix 2600Z
- FinePix 2650
- FinePix 2650Z
- FinePix 2800
- FinePix 30i
- FinePix 345
- FinePix 345 zoom
- FinePix 40i
- FinePix 4500
- FinePix 4500 Plus
- FinePix 4700 zoom
- FinePix 4700Z
- FinePix 4800
- FinePix 4900



- 
- FinePix 6900
  - FinePix A101
  - FinePix A201
  - FinePix A202
  - FinePix A203
  - FinePix A203 zoom
  - FinePix A204
  - FinePix A204 zoom
  - FinePix A205
  - FinePix A205 zoom
  - FinePix A210
  - FinePix A210 zoom
  - FinePix A301
  - FinePix A303
  - FinePix A303 zoom
  - FinePix A303,
  - FinePix A310
  - FinePix A310 zoom
  - FinePix A330
  - FinePix A330 zoom
  - FinePix A340
  - FinePix A340 zoom
  - FinePix A345
  - FinePix A350
  - FinePix A350 zoom
  - FinePix A370
  - FinePix A403
  - FinePix A405
  - FinePix A405 zoom
  - FinePix A500
  - FinePix A605
  - FinePix A607
  - FinePix A607 zoom
  - FinePix DX-5
  - FinePix E500
  - FinePix E500 zoom
  - FinePix E510
  - FinePix E510 zoom
  - FinePix E510,
  - FinePix E550
  - FinePix E550 zoom
  - FinePix F401
  - FinePix F410
  - FinePix F420
  - FinePix F420 zoom
  - FinePix F601
  - FinePix F610
  - FinePix F700
  - FinePix MX1500
  - FinePix MX-40i
  - FinePix Q1 Digital
  - FinePix S3000
  - FinePix S5000
  - FinePix S602
  - FinePix S7000

**Kodak:**

- EasyShare C330
- EasyShare C340
- EasyShare C360
- EasyShare C503
- EasyShare C533
- EasyShare C603
- EasyShare C633
- EasyShare C643
- EasyShare C653
- EasyShare C663
- EasyShare C703



- 
- EasyShare C743
  - EasyShare C875
  - EasyShare CD33
  - EasyShare CD43
  - EasyShare CW330
  - EasyShare CX4200
  - EasyShare CX4210
  - EasyShare CX4230
  - EasyShare CX4300
  - EasyShare CX4310
  - EasyShare CX6200
  - EasyShare CX6230
  - EasyShare CX6330
  - EasyShare CX6445
  - EasyShare CX7220
  - EasyShare CX7330
  - EasyShare CX7430
  - EasyShare CX7525
  - EasyShare CX7530
  - EasyShare DC200
  - EasyShare DC200 Plus
  - EasyShare DC210
  - EasyShare DC210 Plus
  - EasyShare DC215
  - EasyShare DC220
  - EasyShare DC240
  - EasyShare DC240i
  - EasyShare DC260
  - EasyShare DC265
  - EasyShare DC280
  - EasyShare DC290
  - EasyShare DC3200
  - EasyShare DC3400
  - EasyShare DC5000
  - EasyShare DX4330
  - EasyShare DX4530
  - EasyShare DX6340
  - EasyShare DX6440
  - EasyShare Z612
  - EasyShare Z650
  - EasyShare Z700
  - EasyShare Z710
  - EasyShare Z712 IS
  - EasyShare Z740
  - EasyShare Z812 IS
  - EasyShare Z885
  - EasyShare Z1012 IS
  - EasyShare Z1085 IS
  - EasyShare Z1275
  - EasyShare Z1285
  - EasyShare Z8612 IS
  - EasyShare ZD710

**Panasonic:**

- DMC-LC20
- DMC-LC33
- DMC-LC43
- DMC-LC50
- DMC-LS1
- DMC-LZ1
- DMC-LZ2

---

**Zasilacz do aparatu cyfrowego Kodak / Fuji / Panasonic**

