



Zasilacz VSK0325 / AC-3VN

Cena	99,90 zł
Dostępność	Dostępny
Czas wysyłki	1-2 dni robocze
Numer katalogowy	zs213240
Kod producenta	KD-AC3V
Producent	B&W

Opis produktu

Zasilacz do Fuji / Panasonic

- 3V / 2A
- wymiary: 81 x 47 x29 cm
- waga: 142 g

Wymiary wtyczki: zewnątrz 2,35 mm, wewnątrz 0,7 mm.

W zestawie kabel zasilający z wtyczką europejską.

Zastępuje zasilacze:

- 1543855115
- 600003504
- AC3AG, AC-3AG, AC3V, AC-3V, AC3VHSUS, AC-3VHS-US, AC-3VHS-US, AC3VN, AC-3VN, AC-3VN, AC3VS, AC-3VS, AC-3VS
- DMW-AC1
- KWS0325
- PAN0325B
- VSK0325

Stosowany w aparatach:

Fuji:

- DS-10
- FinePix 1300
- FinePix 1500
- FinePix 2300
- FinePix 2400
- FinePix 2600
- FinePix 2600 zoom
- FinePix 2600Z
- FinePix 2650
- FinePix 2650Z
- FinePix 2800
- FinePix 30i
- FinePix 345
- FinePix 345 zoom
- FinePix 40i
- FinePix 4500
- FinePix 4500 Plus
- FinePix 4700 zoom
- FinePix 4700Z

-
- FinePix 4800
 - FinePix 4900
 - FinePix 6900
 - FinePix A101
 - FinePix A201
 - FinePix A202
 - FinePix A203
 - FinePix A203 zoom
 - FinePix A204
 - FinePix A204 zoom
 - FinePix A205
 - FinePix A205 zoom
 - FinePix A210
 - FinePix A210 zoom
 - FinePix A301
 - FinePix A303
 - FinePix A303 zoom
 - FinePix A303,
 - FinePix A310
 - FinePix A310 zoom
 - FinePix A330
 - FinePix A330 zoom
 - FinePix A340
 - FinePix A340 zoom
 - FinePix A345
 - FinePix A350
 - FinePix A350 zoom
 - FinePix A370
 - FinePix A403
 - FinePix A405
 - FinePix A405 zoom
 - FinePix A500
 - FinePix A605
 - FinePix A607
 - FinePix A607 zoom
 - FinePix DX-5
 - FinePix E500
 - FinePix E500 zoom
 - FinePix E510
 - FinePix E510 zoom
 - FinePix E510,
 - FinePix E550
 - FinePix E550 zoom
 - FinePix F401
 - FinePix F410
 - FinePix F420
 - FinePix F420 zoom
 - FinePix F601
 - FinePix F610
 - FinePix F700
 - FinePix MX1500
 - FinePix MX-40i
 - FinePix Q1 Digital
 - FinePix S3000
 - FinePix S5000
 - FinePix S602
 - FinePix S7000

Kodak:

- EasyShare C330
- EasyShare C340
- EasyShare C360
- EasyShare C503
- EasyShare C533
- EasyShare C603
- EasyShare C633
- EasyShare C643
- EasyShare C653

-
- EasyShare C663
 - EasyShare C703
 - EasyShare C743
 - EasyShare C875
 - EasyShare CD33
 - EasyShare CD43
 - EasyShare CW330
 - EasyShare CX4200
 - EasyShare CX4210
 - EasyShare CX4230
 - EasyShare CX4300
 - EasyShare CX4310
 - EasyShare CX6200
 - EasyShare CX6230
 - EasyShare CX6330
 - EasyShare CX6445
 - EasyShare CX7220
 - EasyShare CX7330
 - EasyShare CX7430
 - EasyShare CX7525
 - EasyShare CX7530
 - EasyShare DC200
 - EasyShare DC200 Plus
 - EasyShare DC210
 - EasyShare DC210 Plus
 - EasyShare DC215
 - EasyShare DC220
 - EasyShare DC240
 - EasyShare DC240i
 - EasyShare DC260
 - EasyShare DC265
 - EasyShare DC280
 - EasyShare DC290
 - EasyShare DC3200
 - EasyShare DC3400
 - EasyShare DC5000
 - EasyShare DX4330
 - EasyShare DX4530
 - EasyShare DX6340
 - EasyShare DX6440
 - EasyShare Z612
 - EasyShare Z650
 - EasyShare Z700
 - EasyShare Z710
 - EasyShare Z712 IS
 - EasyShare Z740
 - EasyShare Z812 IS
 - EasyShare Z885
 - EasyShare Z1012 IS
 - EasyShare Z1085 IS
 - EasyShare Z1275
 - EasyShare Z1285
 - EasyShare Z8612 IS
 - EasyShare ZD710

Panasonic:

- DMC-LC20
- DMC-LC33
- DMC-LC43
- DMC-LC50
- DMC-LS1
- DMC-LZ1
- DMC-LZ2

Zasilacz do aparatu cyfrowego Kodak / Fuji / Panasonic